INSTALLATION GUIDE

Note: This product must be installed by a licensed plumber. This is a general installation guide - there are many factors involved that can alter the installation method. **AU/NZ:** For installations within Australia and New Zealand, this product must be installed in compliance with AS/NZS 3500. **UK:** For installations in the United Kingdom this product must be installed in compliance with the Water Supply (Water Fittings) Regulations and Water Supply (Water Fittings) (Scotland) Byelaws. **Other:** For installations outside these countries, this product must be installed in compliance with the standards in your respective country.



Inwall Mixer Body and Spout Pipe Installation

I5mm pipe exiting the top of the valve then directed to the spout location using 90 degree elbows, or other suitable fittings depending on required spout location.

Use appropriate thread sealant

Half inch elbow back plate,
I5mm inlet orientated to the top.

Use appropriate thread sealant



Regularly clean with mild

liquid detergent or soap

and water



